

- MANHOLE CUT-OUT MUST BE MADE AT TIME OF INSTALLATION 2.
- 3. MANHOLE TO BE INSTALLED BY INSERTING INTO WET CONCRETE BASE.
- 4. FOR CONNECTIONS OF PVC THROUGH MH WALL, PROVIDE SEALANT BETWEEN PIPE AND MANHOLE. STAUFFER CHEMICAL SW94ORTV SILICONE SEALANT, OR APPROVED EQUAL.
- 5. THE SOIL UNDER THE 6" MINUMUM CONCRETE SLAB SHALL BE UNDISTURBED.
- 6. MANHOLE SHALL WITHSTAND H-20 LOADING.

the right place in Texas

DRAWN BY: LA DATE: Nov. 30 ,2016 SCALE: N T S

S FILE